


INSTALLATION INSTRUCTIONS --- Rack End Caps

Fig. 1



The ENDCAP option for your Rack is available in 25" depth (see Fig. 1).

Selection of this option requires a 25" depth Rack. This option includes 2 each ENDCAPS and 12 each 10-32 rackmount screws.

ENDCAPS are heavy gauge steel with a flat black powder coating. ENDCAPS can be installed either on the side top and/or bottom of your Rack. They provide additional reinforcement of the overall Rack structure in addition to covering the side (top and/or bottom) of your Rack.

Fig. 2



Once you've completed the assembly of your Rack, place your ENDCAPS at the top and/or bottom sides of your finished assembly so the specially notched out corners mate with the RackFrame corner connectors (see Fig. 2). This is most easily done if you lay the Rack on its side. Once in place, fasten the ENDCAPS with 6 each 10-32 rack screws.

Perform same operation for opposite side.