

INSTALLATION INSTRUCTIONS -- Rack Side Panels

Fig. 1




The SIDE PANEL option for your Rack is available in various sizes corresponding to the height of your Rack. All SIDE PANELS are produced to fit 20", 25" or 30" rackable depth Racks (see figure 1).

For Racks of 4 RU to 35 RU in height, each SIDE PANEL is precision cut with specially routed corners to fit the sides of your Rack (see figure 2).

For Racks of 36RU to 43RU height your side panels are supplied as a 2-part hinged assembly for each side to minimize freight costs for the side panels by staying within allowable carrier dimensional size constraints (see figure 3).

Fig. 2



Installation is easier if Rack is carefully laid on its side. Lay SIDE PANEL with depth dimension spanning the front to rear dimension of Rack on side of Rack. Use the supplied 10-32 rack screws and plastic washers to fasten your SIDE PANEL to your Rack. **DO NOT OVER TIGHTEN SCREWS.** Once all screws are in place and tightened, perform the same procedure on the opposite side of your Rack.

Fig. 3

